

FBIM Manual Instruction

English

About The Host



FBIM

Bluetooth Version:3.0
BC5 Chipset:CSR BC5
Battery: 850mA
Battery Type: Polymer
Charge and Discharge times:500
Working Voltage:3.3V-4.2V
Talking Time:12Hrs

Standby Time: 360Hrs
Charging Time: 3Hrs
Speaker Power:0.25W
Waterproof: IP65
Working Temperature:-10°C
+45°C
Charging Adapter: DC 5V 500mA

1

English

3.5mm Two-In-One Jack Schematic



3.5mm Two-In-One Jack on the bottom.It can connect with earphone as audio output,or connect with charging cable



When use,please plug standard earphone in the 3.5mm Two-In-One Jack

Turn on the host

Hold the power on button for about 2 seconds,then the red light goes on,release when the blue light flashes,it enters into on mode

Turn off the host

Press power off key and A key 2S simultaneously.

Charge the host

Plug the standard power adapter in 3.5mm Two-In-One Jack to charge the host

FBIM Pairing Instruction

TWO-WAY INTERCOM PAIRING

Before Pairing,in the state of power on,long press Volume Up and Volume Down button at same time to clear the pairing records.

- Step 1: Turn On Device 1 and Device 2,now both two intercoms flicker blue light
Step 2: Press Channel A Button of device 1 and Channel B Button of device 2 about 3-5 seconds,till Indicator Light flicker between red and blue,then release.
Step 3: And then press Channel A button of Device 1 just once,Device 1 blue light flashes,and it starts to search Device 2.About 3-5 seconds later,Device 1 and Device 2 will all blue light flash in same frequency,now two devices pairing successfully.
Step 4: Now Just short press Channel A button of Device 1,you can enter intercom status.

2

English



To clear, mark 4pcs intercoms 1,2,3,4 as below figure.

- Step1:First pair Device 1 with Device 2 as above.
Step2:Then pair A button of Device 2 with B button of Device 3,after Device 2 and Device 3 in intercom status,then pair A button of Device 3 with B button of Device 4,after Device 3 and Device 4 in intercom status,just short press Off Button of 4 device once.
Step3:Now you need turn on 4pcs intercoms again,all flash blue light,short press A button of Device 1 twice.Wait about 10 seconds,the 4 devices will automatic search each other and connect,The Four-Way Conference Intercom Pairing is now complete and ready to use.
Step4:After all 4pcs devices connect successfully,Indicator Light of each device will show different color:Device 1 red flash,Device 2 and Device 3 red and blue mix flash,Device 4 blue flash.



THREE-WAY INTERCOM PAIRING

Operate as above FOUR-WAY INTERCOM PAIRING,the different is not pair device 4.

3

English



Record pairing history:1.Turn on all device . 2. Press Device 1 button A twice,wait 10 seconds,and then connect successful(Light of each device will show different color : Device 1 red flash,Device 2 and Device 3 red and blue mix flash,Device 4 blue flash)

CONTENTS OF RETAIL BOX



4