





Eagle

User Manual

Intercom Device Instructions



- 1 Power On
- 2 Mobile Phone Button
- 3 Volume Up
- 4 Volume Down
- 5 LED Indicator light
- 6 Slot/Fixed



7 Earphone Port 8 USB Port/Charging Port

Installation Instructions:

(Pairing before installation)

[Intercom Device Installation]





1.First make colorful rings through the helmet by hook to fixed intercom device (Fixed by 1pc to 3pcs Colorful ring)

[Intercom connect]



2.Connect headphones with intercom through the nearest gap on the helmet

[Earphone Installation]



3.Wear the helmet to find the appropriate location of the ear, remember it and then stick the headset backside to the inside of the helmet hand



4. Stick velcro on back side of headset to fix it.

[Microphone Installation]



5.Connect the microphone to the headset cable

6.Attach microphone to the earphone velcro position.



7. Find the right position, sticky, and then adjust the headset direction.

[Fix the cables]





8. Remove the white sticker from the back of the Velcro



9. Use the Velcro to fix the cables

[Final image of the installation]





[Power On/Off operation]



[Power on] Long press the button 1 about 2S,blue light flash, voice prompt 'Power on"



[Power off] Press button 1 and button 2 at the same time about 2 s, red light on, voice prompt 'Power off'

【Connect Mobile Phone/MP3/GPS Device】

[Pairing with Mobile Phone]

At Power off stage, press button 1 about 5s, release when red and blue light alternately flashing. Open the mobile phone bluetooth,find EAGLE and connect, voice prompt 'Pairing'.

[Pairing with other brands Bluetooth headset]

Eagle On Power off state, long press button 1 about 5s release when red and blue light alternately flashing, other brands Bluetooth headset on pairing state, then short press the Eagle button 1 to create a pair. After pairing successfully, short press Eagle button 1, intercom talking after 3s.



[Operate mobile phone through intercom]

[Memory reconnection]

Intercom off or shutdown, reboot, short press the phone key, you can reconnect the phone.

[Answer phone call]

When calling, it will automatically receive the phone call after

8s. Or short press button 2 to answer

[Refuse to answer phone call]
When calling, double-click button 2 to reject.

[End phone call]

During the call, short press button 2 to hang up

[Disconnect any intercom] when Intercom, short press button 1 to disconnect any intercom.

[Voice dialing] In the state of power on and connected mobile phone, quick click button 3 twice

[Music Move Next/Move Previous] In the music playing sate, click button 3 twice or button 4 twice.

[Clear all pairing history] Press button 1 and 3 at the same time about 0.2S, clear all pairing history

[Last phone number redial] In the sate of power on and connected mobile phone, press button 4 twice ,voice promt "Redialing"

[Volume Adjustment] In the state of intercom, calls, music,long press Button 3/ 4 to adjust the volume. [Charging Indicator] Indicator light on red When charging and off after full charge

[Intercom Pairing]

Two Eagle in power off state, long press button 1 about 3-5 seconds, release when red and blue light alternately flashing, and then just short press one Eagle button 1(now its blue light flashing)

About 5s, when two Eagle flshing blue light in same frequency mean pairing established, Short press either Eagle button 1, after 3s you can enter intercom status.





[Charging]









Use standard USB cable in the package, insert USB cable into intercom charging port / USB port,connect another side with power bank / power adapter for charging

[Packing contents]



1.One Pair headset and microphone



2. Four Velcro



3.USB charging cable



4. Colorful ring, hook

Specification
Bluetooth:Bluetooth V3.0+EDR
Battery voltage:3.7V
Bluetooth files: A2DP AVRCP HS/HF
Working temperature:-40℃ to 60℃
Intercom wireless transmission range:1200M(under ideal conditions)
Frequency range: 2.402 GHZ—2.480GHZ
Mobile phone connection transmitting range:10M
Talking time: More than 12hrs
Charging time:About 2 hrs
Music playing time:about 8 hours
Battery type: Li-Polymer 530mA

[Safety precautions]

Standby time: More than 320hrs

- 1. During the riding, any changing the setting of this product, cellphone pairing operation is prohibited in order to avoid any traffic accidents.Do not operate this product when you riding.
- If product is smoking, hot, odour, please cut off power supply immediately, and stop using it, So as not to cause an electric shock, fire and other accidents.
- Please do not put this product into the fire, the built-in battery has the possibility of an explosion.
- Please do not do STH without authorization remove, modification of this product, maybe will lead to product defects, and get an electric shock, fire accidents, etc.

(Abnormal case handling)

Because of the water inside the product, or fall, impact and other causes of casing damaged, and abnormal voice, smoke, odour, such as abnormal happens, please immediately cut off the power and stop using it.lt is strictly prohibited to disassembly and repair by customer.

[Warning]

- 1. Avoid harmful behaviors of the products, such as drop and shock, otherwise it will cause malfunction.
- Please do not put the product near the fire or direct sunlight for a long time.
- 3. Keep this product away from children.
- 4. Usinf this product within 40 $^{\circ}$ C to 60 $^{\circ}$ C temperature environment, higher or lower than the temperature, will be no guarantee of normal using.
- 5. The standard product accessories are verified by test, suggest use our verified accessories.

(Note for charging)

- 1. Please use our company's accessories USB cable for charging, lest cause the occurrence of smoke, fire, and so on.
- If long time of no using this product, at least one time charge behavior every year, lest can't open the machine and the damage to the battery.
- When charging, please use the power adapter and at room temperature, please avoid recharged in near fire place, lest cause smoke, even fire.
- 4. In the process of charging, Odour, burning, etc., please immediately cut off the power and stop using it. In order to avoid the smoke and fire accidents.