


EJEAS®


Q7

User manual

Top Quality Hi-Fi
Motorcycle Bluetooth Intercom




Product Details




Product Installation


1




or




2




3



4




5




Product Operations

Operation Diagram




Click




Double-click



Triple-click




Long-press for 5s



Simultaneous click


Basic Operations

Power ON/OFF Please charge it before using.



ON ? "Ding~Ding~Ding~Ding~"

Standby ▶ Blue light flashes slowly



OFF


Click the <Phone Button> and <FM Button> simultaneously.

▶ Lights off

Battery Level



or




? "Battery Level High"

? "Battery Level Medium"


? "Battery Level Low"

Low Battery Indication



Red light flashes twice
? "Low Battery"

Charging Indication





Charging Red light always on
Full Red light off



Volume Control

FM and intercom can be used at the same time.


Intercom / Calling / Music / FM



When intercom & FM used simultaneously, FM volume control



Factory Reset




Long press the <Volume +>, <Volume ->, <Phone Button> for 5s at the same time.

Red light quick flashes three time,
blue light flashes once

? "Restore Default Setting"

Bluetooth Intercom

Two-Intercom Pairing



1 Long-press <A Button> for 5s of both.

Red and blue lights flash fast alternately

? "Intercom A Pairing"

Searching and paring.

Paring successfully.

Blue light flashes simultaneously

? "Intercom Pairing Successful"

Connected, start communication.


? "Intercom A Connected"

Multi-Intercom Pairing (3-7 models)


All the following voice prompts refer to the host.

Regard one as host, the rest are all sub-intercom.


- A Button for pairing of 3 sub-intercom
- B Button for pairing of 3 sub-intercom




A sub-intercom




C sub-intercom




E sub-intercom




Host



B sub-intercom




D sub-intercom




F sub-intercom

Pair with A sub-intercom



Pair with B sub-intercom



Pair with C sub-intercom

3 Long-press <A Button> for 5s of both.

Pair with D sub-intercom

4 Long-press <B Button> for 5s of both.

Pair with E sub-intercom


5 Long-press <A Button> for 5s of both.

Pair with F sub-intercom

6 Long-press <B Button> for 5s of both.

(Recommend marking all the intercom for easy switching)


Intercom Switching Only the Host allows to switch.



Click to talk
to A intercom



Double-click to talk
to C intercom



Triple-click to talk
to E intercom



Click to talk
to B intercom



Double-click to talk
to D intercom




Triple-click to talk
to F intercom

- Intercom switching
- Start talking
- Blue light quick flashes


Blue light flashes simultaneously

Intercom Disconnection




? "Intercom Disconnected"

Compatible with Old Intercom Pairing



1 Long press < A Button > for 5s, while V4/V6 enter the pairing mode.

- Red and blue lights flash fast alternately
- ? "Intercom A Pairing"



2 Click < A Button > enter Bluetooth search mode.

- Red and blue lights flash twice alternately
- ? "Intercom A Searching"


Paring successfully.

- Blue light flash fast
- ? "Intercom Pairing Successful"

Connected, start communication.
? "Intercom A Connected"

Bluetooth Pairing


Phone Pairing



① Long press the <Phone Button> for 5s to enter the pairing mode.

(If no phone connected, it will exit pairing mode after 2 mins)


Red & blue lights flash fast alternately
"Phone Pairing"



② Open your phone's Bluetooth, search and pair with the device.

Pairing successful

Blue light twice flashes slowly
"Pairing Successful, Connected"




Current power will be shown on your phone.
(Phone must support HFP)

Phone Reconnection

Automatically connect back to the last paired.

or




Mobile Phone


Answer a Call

Auto answering within 8s if no any operation.


or




Reject a Call




Last Call Replay



End a Call




TEL Priority When listening to music/FM/intercom, and receiving a phone call.




Voice Assistant

Phone must support & open the voice assistant (Google assistant & Siri).





Music Control

Music Play/Pause




Music Switching



FM Radio

FM ON/OFF 76~108MHz

Auto search and radio, intercom and radio could working at the same time.



Long press <FM Button> for 1s to open the FM.

Blue light is always on for 4s


Red light double flashes quickly

? "FM Radio"


Long press <FM Button> for 1s to close the FM.

? "FM Radio Off"

Frequency Switching



Frequency -



Frequency +

SafeRiding APP

The EJEAS SafeRiding App allows you to set up your group and stay connected with your friends. Save time and enjoy your adventure even more! You can also see more product operations precautions and multiple language operations! Download the EJEAS SafeRiding App for Android and Apple operating systems from ejeas.com/support.

SafeRiding
APP



iOS



Andriod

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation